

Dogness Smart Fountain User Manual



BEFORE USING THIS PRODUCT, PLEASE READ THIS MANUAL.

Thank you for purchasing DOGNESS smart products. For your safety and concern, please read this product manual carefully prior to use. Failure to follow and operate this product in accordance within the manual and issues that result in any personal injury, property or other losses, DOGNESS has no liability except as expressly provided by law.

ABOUT THE PRODUCT MANUAL

The authorization, trademark, and font size of the manual belong to DOGNESS and other related parties. If the content of the manual is inconsistent with the actual product (including APP), the actual product (APP) shall prevail. DOGNESS reserves the right (including electronic version) to interpret and modify the manual within the scope permitted by law. If you have any objection to any content or terms of the manual, please submit a written objection to DOGNESS: within 7 days after purchasing the product. Otherwise you agree, understand and accept the entire contents within this user manual.

SPECIFICATIONS

Product Name: Dogness Smart Fountain

Size: L 7.8" x W 9.13" x H 6.81"

Weight: 1.98 lbs.

Material: ABS Capacity: 2 Liters

Filtration: Carbon filter / Nano filter / Cotton filter

Power: DC 5V 130mA


FEATURES:

- Non-inductive electric design, safe for all
- Triple water filtration system removes impurities and odor
- Ultra-guiet 5V water pump, guiet and not disturbing
- Smart dry-run protection, auto shut-off when water level is low
- Lighted viewing window makes the water level easy to spot
- Uninterrupted and consistent operation, more durable performance
- Low energy consumption, less than 1KW per month

PRODUCT LIST

Power adapter X1

Before using, please confirm that the product accessories are complete









Nano filter box X1





PRODUCT OVERVIEW

DOGNESS

Carbon filter box X1

 Diversion tube 2 → Water level indication

─ Top bowl

Diversion tube 1

Nano filter box

─ Water fountain body

Entrusting Party: Dogness Group LLC


Address of Entrusting Party: 4116 W Spring Creek Pkwy, Plano, TX 75024 Manufacturer: Jiasheng Enterprise Co., Ltd.

Address of Manufacturer: No. 3 W Yuehua Rd, Tongsha New Industry Park, Dongguan, Guangdong, China 523127


Website: www.dogness.com


Customer Service Hotline (U.S.): 1-833-DOGNESS (364-6377)

PRODUCT OVERVIEW



PRODUCT INSTRUCTIONS






3. Align the top cover with the water pipe of the base and cover the fountain


T T /




MAINTENANCE AND CLEANING



Unplug the power supply, open the top cover, and disassemble the diversion pipe and pump



 2. Rinse the water pump parts, and clean the base bowl and the top cover of the fountain




3. Assemble the diversion pipe and the water pump before putting together the base bowl and the top cover. Plug in the power supply and ready to use.

RECOMMENDATIONS ON CLEANING

Top cover: Clean once or twice a week Carbon filter box: Clean 1-2 times a week, replace every 1-2 months

Nano filter box: Clean 1-2 times a week Diversion pipe: Clean 1-2 times a week Base bowl: Clean 1-2 times a week

INSTRUCTION ON FILTER REPLACEMENT



1. Push the old filter box out of the top cover slot, replace it with a new filter box.



Align the filter box with the top cover slot and push the filter box in to complete the replacement.

PRECAUTIONS

- 1. Do not pull the power cord directly when plug in/out the adapter.
- Promtly add water or stop using the mini fountain once the water line is lower than the water pump's height.
- 3. Do not run the water pump without water.
- Attention: The damage caused by the dry- run water pump are not covered under warranty.
- 4. Do not put the power adapter in the place that pets can easily reach.
- For indoor use only. Pull out the power cord and adapter before cleaning the product.
- Please use the power adapter and pump that come with the product only.
- 7. This device contains electronic parts, and is not water proof. It is highly recommended to keep device away from water.
- 8. If the product shows malfunctions, odor, smoke, abnormal heat,
- please stop using this product, and contact customer service
- 1-833-Dogness [364-6377].
- If you have any other question, please visit following website for more information.

Website: www.dogness.com

Q

- 1. Why are the noises from the water pump louder than the previous version of the fountain?
- Answer: 1): Probably the water line is too low, please add water.
 - 2]: Probably because hair is stuck in the pump paddle, please disassemble the pump and clean accordingly.
- 3]:Operate the water pump without adding water.
- 2. How long should the smart fountain be cleaned?
- Answer: It's suggested to clean once a week. No need to add cleansers, just use wipes and clean water directly.
- 3. Is it normal that the power adapter is heating and feel burn at hand after the smart fountain running on?
- Answer: It's normal to have slight heating.
- 4. Is it safe to put the water pump running in the water for a long time? Does this operation consume the power?
- Answer: The water pump adapter 12V safety voltage, which absolutely safe to human and pets.
- 5. What materials was the fountain main body, filter unit and pump making of?
- How long can it be used?

 Answer: The water fountain,

Answer: The water fountain, filter box, and water pump all use imported ABS materials, which meet the safety standards of China, the United States, Germany, Japan and other countries. It is suggested to change the filter unit 1-2 months.